



How to Replace Your Vacuum's Dust Bag

BISSELL Part # 203-7270



1. Unplug the vacuum from electrical outlet.
2. Disconnect hose.
3. Open the dust bag compartment by lifting up on the latch on the door at the front of the vacuum. Lift out the dust bag holder and dust bag.
4. Place dust bag holder and dust bag into the dust bag compartment, making sure the entire bag is tucked in below the seal gasket.
5. Close dust bag compartment door and press down gently until it locks into place.
6. Reconnect hose.

NOTE: Vacuum will not suction while the Bag Door is removed.

Need help?

Call:

1-800-237-7691

Mon-Fri: 8am to 10pm ET

Sat: 9am to 8pm ET

Visit:

www.bissell.com/contact-us

To help keep your product running its best, purchase genuine parts and accessories directly from BISSELL.

www.bissell.com